

15.25.000-1 Sauna Hinge F/Glass Doors, "Trebisov", Brown Powder Painted,



#1 Pull off the 2 threaded rods (no tools needed)



#2 Loosen the center insert screw and push out the center pin (Allen key size 2mm. needed)

Tip: Using a small hammer, knocking lightly on the pin, makes it easier to remove the pin.



#3 Insert the M8 threaded rods into your door frame – holes having a center-to-center distance of 45 mm.

Make sure to insert the threaded rods in the same dept making them aligned (same dept to ensure easy center pin installment) .

Assemble the rest of the hinge.

Tip: Mounted directly into wood, -insert the rods into a $\varnothing 7,5$ mm. hole.